



## Checking your PIN pad's Certification for MX9 Series

**Note:** The document images are from an MX915 device. The tabs/instructions still apply to the MX925.


1. Boot the PIN pad into System Mode by pressing 1-5-9 on the keypad.
2. Login to the Supervisor user with the proper password. Note the password may vary depending upon the device owner's preference.



3. Use the Arrow Key on the Tab menu to Arrow to the right until you see the Security Tab.




4. Select the Security Tab on the screen.




## Checking your PIN pad's Certification for MX9 Series

**Note:** The document images are from an MX915 device. The tabs/instructions still apply to the MX925.

5. Press the right arrow button until you see the "Verishield Tree" tab.



6. Scroll down using the hidden scroll bar on the right of the S/N boxes until you see a listing with "Application." Note: Tap the bottom right corner of the screen.



7. The area under the "Application" box will display the certification that is installed. In the example below "NCR" certification has been installed.

