



Changing Comms on MX9xx

- Once device is powered on press 1, 5, and 9 all at the same time.
- When prompted, enter 166832 to log in as supervisor.
- Follow the path
 - Administration>Config>Config.usr1
 - Config
- Give the device a second to compile the parameters.
- Once in Config.usr1, scroll down until you see “commtype” on the field to the left.
- Select the text that displays the current comm type and give the device a second to pull up the keyboard.
- Delete the current listing and choose one of the comm types from the list below. and Write in “TCPIP” instead.
 - COM1
 - USB
 - TCPIP
- Press Enter to save your choice.
- Hit the “Home” button again and press Reboot on the main menu options.
- The device will boot to TCPIP mode.