



## Checking OS version MX9xx

1. Enter the device as a supervisor by pressing the 1,5, and 9 buttons. This will bring you to a menu that asks you to input a password (password below).
  - a. Password: 166832
2. Once in the system menu, select the "Information" tab.
3. From here, select the "Basic System" tab.
4. At this point, you scroll all the way to the bottom and find the build version as seen below.

The screenshot shows a menu titled "Home > Info > Basic System". Below the title are three tabs: "Basic System", "Ports & Options", and "Installed S/W". A blue arrow points to the right. Below the tabs is a table with the following data:

SDI version	OS. 13
U-Boot Version	2009.11-vf.1.0.19.2501
Kernel Version	2.6.31.14-vf.1.2.18.2504
RFS Version	1.0.38.2516
<b>Build</b>	<b>release-30250800</b>
SOC Revision	VF2101-D0
CIB	915