




Telium2 – Internal Screen Calibration

1. Reboot the device and let it run until it reaches the Retail Base App system information screen. (see below)



2. Once the device is at the above screen, quickly input the following password 2,6,3,4, Enter (the screen will tell you to press the plus button afterwards).
3. Select the Telium Manager option
4. Select the initialization option
5. Select the Hardware option
6. Select the Calibration option
7. Select YES and hit enter.
8. DO NOT TOUCH SCREEN WHILE DEVICE IS CALIBRATING.
9. Reboot the device and try to run a sale. It should work.